



MAT INSTALLATION GUIDE LINES

Dear client,

We at Goplast appreciate your support in purchasing our high quality PVC interlocking mats. We manufacture them in mainly black and dove grey.

We however want to share some installation tips with you:

1. As seen, our mats has certain flexibility thus can be placed on an uneven or flexible surface, preferably flat and smooth;
2. It is important that the surface used is clean, dry and even;
3. If high human traffic, the mats must be glued using PEKAY-A660;
4. In areas where vehicles are driven the mat must be glued;
5. In normal areas the mats could be placed on a clean, dry, smooth surface and would not shift;
6. Do not fit in high temperature areas;
7. Do not burn the mat;
8. The mats are not resistant to all chemicals;
9. When using edging, glue the mats; place the mat in the edge not the edge in the mat
10. Start in a straight line from the front to the back of a room and in the middle to the sides;
11. Use Handy Andy and water to clean;
12. The material used to manufacture our mats is similar to what is used to isolate electrical cables and contain a certain amount of antistatic agent, but is not guaranteed to be antistatic.

Any enquiries regarding the glue can be done directly at the PEKAY GROUP. E-mail : infojhb@pekaygroup.co.za or telephone 012 333 8797 / 011 309 1500 or www.pekaygroup.com

Should you require any further technical information, please do not hesitate to contact our offices at telephone 072 270 9928 or fax 086 684 1944.

Kind regards,

Goplast Team